# iilus


## **Installation Manual**


#### Accent 100 Recessed IP Fixed Type 1


100 10 0061 --.--


Power	8W
Voltage	240V-AC
Class	III
Ingress Protection	IP44
Cut-Out	Ø92 x 92mm Depth

















#### Installation

- Cut 92mm diameter round aperture.
- 2 Plug driver into luminaire.
- 3-4 Fold back retention blades and insert luminaire into the aperture.

### Maintenance

- 1 To access internal housing, remove facade by unscrewing anti-clockwise.
- 2 To remove the module housing, push back metal tabs using flathead screwdriver.
- Twist the module housing, allowing it to drop out through tab slots.



illus.com C