
Installation Manual


Accent 100 Recessed Asymmetrical Type 1


100 10 0021 --.--


Power	8W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø92 x 92mm Depth

















Installation

- Cut 92mm diameter round aperture.
- 2 Plug driver into luminaire.
- 3-4 Fold back retention blades and insert luminaire into the aperture.

Maintenance

- 1 To access internal housing, remove facade by unscrewing anti-clockwise.
- 2 To remove the module housing, push back metal tabs using flathead screwdriver.
- 3 Twist the module housing, allowing it to drop out through tab slots.



iilus.com


Installation Manual


Accent 100 Recessed Asymmetrical Type 1


100 10 0021 --.--


Power	14W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø92 x 150mm Depth

















Installation

- Cut 92mm diameter round aperture.
- 2 Plug driver into luminaire.
- 3-4 Fold back retention blades and insert luminaire into the aperture.

Maintenance

- 1 To access internal housing, remove facade by unscrewing anti-clockwise.
- 2 To remove the module housing, push back metal tabs using flathead screwdriver.
- 3 Twist the module housing, allowing it to drop out through tab slots.




iilus.com 0


Installation Manual


Accent 100 Recessed Asymmetrical Type 2


100 10 0022 --.--


Power	8W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø92 x 92mm Depth

















Installation

- 1 Cut 92mm diameter round aperture.
- 2 Plug driver into luminaire.
- 3-4 Fold back retention blades and insert luminaire into the aperture.

Maintenance

- 1 To access internal housing, remove facade by unscrewing anti-clockwise.
- 2 To remove the module housing, push back metal tabs using flathead screwdriver.
- 3 Twist the module housing, allowing it to drop out through tab slots.



iilus.com C


Installation Manual


Accent 100 Recessed Asymmetrical Type 2


100 10 0022 --.--


Power	14W
Voltage	240V-AC
Class	III
Ingress Protection	IP20
Cut-Out	Ø92 x 150mm Depth

















Installation

- 1 Cut 92mm diameter round aperture.
- 2 Plug driver into luminaire.
- 3-4 Fold back retention blades and insert luminaire into the aperture.

Maintenance

- 1 To access internal housing, remove facade by unscrewing anti-clockwise.
- 2 To remove the module housing, push back metal tabs using flathead screwdriver.
- 3 Twist the module housing, allowing it to drop out through tab slots.



iilus.com